

# Pedigo Built-In Double Door OR Cabinet | P-8140-BI



Stock Photo - Options May Vary

## FACTORY NEW

The Pedigo P-8140-BI is a built-in double door operating room cabinet constructed of stainless steel cabinetry designed to maximize storage and space utilization in surgical environments. The cabinet features 3/16" tempered glass doors with stainless steel lockable paddle latches and double panel doors with FDA-approved polyethylene foam for glass shock resistance.

The cabinet incorporates Steril-Gard construction with radius glass panels for easy cleaning and maintenance. Adjustable stainless steel door hinges allow for vertical and horizontal door adjustment and field-level adjustment as needed. The interior includes four stainless steel shelves that are adjustable in 1/2" increments with position aids for flexible storage configuration.

The cabinet is adaptable to custom installations and comes with a three-year warranty. The built-in model is designed for permanent installation in operating room environments where reliable, durable storage is essential.

## FEATURES

- Stainless steel cabinetry to maximize storage and space utilization
- 3/16" tempered glass doors with stainless steel lockable paddle latch
- Double panel doors with FDA-approved polyethylene foam for glass shock resistance
- Steril-Gard construction
- Stainless steel shelves adjustable in 1/2" increments with position aids

## SPECIFICATIONS

- Part Number: P-8140-BI
- Dimensions: 47"w x 24"d x 72"h
- Shelves: 4
- Construction: Stainless Steel
- Warranty

*\*Brochure and images are a general overview of the product. Actual product options may vary.*

Toll-Free | Local  
800-627-3215 | 813-740-8640

[salesteam@venturemedical.com](mailto:salesteam@venturemedical.com)

[View this product online →](#)